



Nr	Partnr	Description	75 Std	76 Std	76 Ltd	77 Std	78 Std	79 Std	Serialnr	Areacode
1	43209-371-006	Seal, piston, 38mm	2	2	2	2	2			
1	43209-431-671	Seal, piston, 38mm						2		
2	43218-371-006	Clip, dust cover	2	2	2	2	2	2		
3	43352-568-003	Screw, bleeder	2	2	2	2	2	2		
4	43353-548-003	Cap, bleeder screw	2	2	2	2	2	2		
5	45100-371-006	Caliper assy., L. FR.	1	1	1	1				
5	45100-371-315	Caliper assy., L. FR.	1	1	1	1				
5	45100-410-006	Caliper assy., L. FR.						1		
5	45100-410-016	Caliper assy., L. FR.						1		
5	45100-410-016	Caliper assy., L. FR.							To 14108136	
5	45100-410-026	Caliper assy., L. FR.							To 14108136	
5	45100-410-026	Caliper assy., L. FR.						1		
6	45101-371-006	Caliper A, L. FR.	1	1	1	1				
6	45101-410-006	Caliper, L.						1		
6	45101-415-006	Caliper, L.							To 14108136	
6	45101-415-016	Caliper, L.						1		
6	45101-415-026	Caliper, L.						1		
6	45102-371-006	Caliper B, FR.	2	2	2	2				
7	45105-371-006	Pad comp.	4	4	4	4				
7	45105-410-004	Pad comp.	4	4	4	4				
7	45105-410-004	Pad comp.						4	To 44009817	
7	45105-410-006	Pad comp.	4	4	4	4	4	4	To 4009817	
7	45105-410-007	Pad comp.	4	4	4	4	4	4	To 44009817	
7	45105-410-016	Pad comp.	4	4	4	4	4	4	To 44009817	
7	45105-410-026	Pad comp.	4	4	4	4	4	4	To 44009817	
8	45107-371-006	Piston	2	2	2	2				
8	45107-410-006	Piston						2		
8	45107-415-006	Piston						2		
9	45108-371-006	Spring, pad	2	2	2	2				
9	45108-410-006	Spring, pad						2		
9	45108-415-006	Spring, pad						2		

Nr	Partnr	Description	75 Std	76 Std	76 Ltd	77 Std	78 Std	79 Std	Serialnr	Areacode
10	45109-371-006	Boot, piston	2	2	2	2	2	2		
11	45110-371-006	Bracket, L. support	1	1	1	1				
11	45110-410-006	Bracket, L. FR.					1			
11	45110-422-006	Bracket, L. FR.						1		
11	45110-422-016	Bracket, L. FR.						1		
12	45112-410-006	Retainer, bracket					4	4		
12	45134-371-006	Retainer, boots	4	4	4	4				
13	45114-371-006	Shim A, pad	2	2	2	2	1	1		
14	45116-371-006	Shim B, pad	2	2	2	2	1	1		
15	45119-371-000	Cap, indicator	2	2	2	2	2	2		
16	45131-371-006	Pin A	2	2	2	2				
16	45131-410-006	Pin A						2	2	
17	45132-371-006	Pin B	2	2	2	2				
17	45132-410-006	Pin B						2	2	
18	45133-371-006	Cover, dust	4	4	4	4	4	4		
19	45200-371-006	Caliper assy. R. FR.	1	1	1	1				
19	45200-371-315	Caliper assy. R. FR.	1	1	1	1				
19	45200-410-006	Caliper assy. R. FR.						1		
19	45200-410-016	Caliper assy. R. FR.						1		
19	45200-422-016	Caliper assy. R. FR.							To 14108136	
19	45200-422-026	Caliper assy. R. FR.							To 14108136	
19	45200-422-026	Caliper assy. R. FR.						1		
20	45201-371-006	Caliper A, R. FR.	1	1	1	1				
20	45201-410-006	Caliper, R.						1		
20	45201-422-006	Caliper, R.							To 14108136	
20	45201-422-016	Caliper, R.							To 14108136	
20	45201-422-016	Caliper, R.						1		
20	45201-422-026	Caliper, R.							To 14108136	
20	45201-422-026	Caliper, R.						1		
20	45201-442-701	Caliper, R.						1		
21	45210-371-006	Bracket, R. support	1	1	1	1				
21	45210-410-006	Bracket, R. FR.						1		
21	45210-422-006	Bracket, R. FR.							1	
21	45210-422-016	Bracket, R. FR.							1	
22	90116-371-000	Bolt, socket, 8x23	4							
22	90116-371-000	Bolt, socket, 8x23		4					To 2016000	
22	90116-371-010	Bolt, socket, 8x23	4	4	4	4				
22	90116-410-006	Bolt, 8x25						4		
22	90116-422-006	Bolt, socket, 8x23							4	
23	90123-371-000	Bolt, FR. Caliper	4	4	4	4	4	4		
23	90123-371-980	Bolt, FR. Caliper			4					
24	90518-001-000	Washer, handle cushion rubber			4					
24	90545-300-000	Washer, oil bolt					4	4		
24	91556-371-980	Washer, plain, 10mm			4					
24	94101-10000	Washer, plain, 10mm			4					
24	94101-10200	Washer, plain, 10mm	4	4		4				
	06455-371-405	Pad set, brake	2	2	2	2	2	2		
	451A0-371-670	Brake pad kit	2	2	2	2	2	2		
	90165-300-023	Bolt, caliper mount	4	4	4	4				