



Nr	Partnr	Description	75 Std	76 Std	76 Ltd	77 Std	78 Std	79 Std	Serialnr	Areacode
1	16010-371-004	Gasket set	4	4	4	4	4	4		
2	16011-371-004	Valve set, float	4	4	4	4	4	4	To 771A	
2	16011-371-014	Valve set, float						4	From 771B	
3	16012-371-004	Needle set, jet	4							
3	16012-371-772	Needle set, jet		4	4	4				
3	16012-431-004	Needle set, jet					4	4		
4	16013-567-004	Float set	4	4	4	4	4	4		
5	16016-371-004	Screw set a	4	4	4	4				
5	16016-431-004	Screw set a					4	4		
6	16022-371-004	Piston set, vacuum	4							
6	16022-371-771	Piston set, vacuum		4	4	4				
6	16022-431-004	Piston set, vacuum					4	4		
7	16165-371-770	Holder, needle jet				4	4	4		
8	16166-371-004	Nozzle, main	4	4	4					
8	16166-371-770	Nozzle, main				4	4	4		
9	93500-04008-0A	Screw, pan, 4x8	4	4	4	4	4	4		
10	93500-04014-0A	Screw, pan, 4x14	4	4	4	4	4	4		
11	93500-05016	Screw, pan, 5x16	8	8	8	8	8	8		
12	94111-04000	Washer, spring, 4mm	8	8	8	8	8	8		
13	94111-05000	Washer, spring, 5mm	8	8	8	8	8	8		
14	94303-04065	Pin c, dowel, 4x6.5		8	8	8	8	8		
15	99103-611-0350	Jet, slow, #35	4	4	4	4	4	4		
16	99164-601-0600	Jet, secondary air, #60	4	4	4	4	4	4		
17	99164-601-1100	Jet, slow air, #110	4			4				
17	99164-601-1150	Jet, slow air, #115		4	4					
17	99164-601-1200	Jet, primary air, #120	4	4	4	4	4	4	To 769A	
17	99164-601-1300	Jet, slow air, #130					4		From 771A	
17	99164-601-1400	Jet, slow air, #140						4	From 771A	
18	99201-601-0620	Jet set, primary main #62		4	4	4				
18	99201-601-0650	Jet set, primary main #65	4							
18	99201-601-0600	Jet set, primary main #60					4	4		
19	99202-601-1250	Jet set, secondary main, #125	4							
19	99202-601-1200	Jet set, secondary main, #120		4	4	4	4	4		