


Nr	Partnr	Description	75 Std	76 Std	76 Ltd	77 Std	78 Std	79 Std
1	30070-371-000	Cover, breaker	1	1	1	1	1	1
2	30079-371-000	Gasket, breaker	1	1	1	1	1	1
3	30200-371-004	Points, assy.	1	1	1	1	1	1
4	30203-292-003	Points, R.	1	1	1	1	1	1
5	30204-292-003	Points, L.	1	1	1	1	1	1

6	30220-431-004	Advancer assy., spark	1	1	1	1	1	1
7	30375-371-000	Case, points	1	1	1	1	1	1
8	30376-371-8000	Gasket, points	1	1	1	1	1	1
9	90441-028-010	Washer, sealing, 6mm	1	1	1	1	1	1
10	90486-028-000	Washer, spark advancer, setting	1	1	1	1	1	1
11	92000-06014	Bolt, hex., 6x14	1	1	1	1	1	1
12	93500-06012	Screw, pan, 6x12	2	2	2	2	2	2
13	93500-06020	Screw, pan, 6x20	4	4	4	4	4	4
14	94101-06000	Washer, plain, 6mm	2	2	2	2	2	2



Serialnr	Areacode

