


Nr	Partnr	Description	75 Std	76 Std	76 Ltd	77 Std	78 Std
1	13011-371-003	Ring set, piston (std.)	4	4			
1	13011-371-004	Ring set, piston (std.)	4	4	4	4	4
1	13021-371-003	Ring set, piston (0.25)	-4	-4			
1	13021-371-004	Ring set, piston (0.25)	-4	-4	-4	-4	-4
1	13031-371-003	Ring set, piston (0.50)	-4	-4			
1	13031-371-004	Ring set, piston (0.50)	-4	-4	-4	-4	-4
1	13041-371-003	Ring set, piston (0.75)	-4	-4			

1	13041-371-004	Ring set, piston (0.75)	-4	-4	-4	-4	-4
1	13051-371-003	Ring set, piston (1.00)	-4	-4			
1	13051-371-004	Ring set, piston (1.00)	-4	-4	-4	-4	-4
2	13101-371-000	Piston (std.)	4	4	4	4	4
2	13102-371-000	Piston (0.25)	-4	-4	-4	-4	-4
2	13103-371-000	Piston (0,50)	-4	-4	-4	-4	-4
2	13104-371-000	Piston (0.75)	-4	-4	-4	-4	-4
2	13105-371-000	Piston (1.00)	-4	-4	-4	-4	-4
3	13112-634-000	Pin, piston	4	4	4	4	4
4	13204-634-020	Bolt, connecting rod	8	8	8	8	
4	13204-371-000	Bolt, connecting rod				8	8
5	13205-634-010	Nut, connecting rod	8	8	8	8	8
6	13210-371-000	Rod assy., connecting	4	4	4	4	4
7	13215-371-003	Bearing a, connecting rod (2&4 blue)	4	4	4	4	4
7	13216-371-003	Bearing b, connecting rod (2&4 black)	4	4	4	4	4
7	13217-371-003	Bearing c, connecting rod (2&4 brown)	4	4	4	4	4
7	13218-371-003	Bearing d, connecting rod (2&4 green)	4	4	4	4	4
7	13219-371-003	Bearing e, connecting rod (2&4 yellow)	4	4	4	4	4
8	13221-371-003	Bearing a, connecting rod (1&3 blue)	4	4	4	4	4
8	13222-371-003	Bearing b, connecting rod (1&3 black)	4	4	4	4	4
8	13223-371-003	Bearing c, connecting rod (1&3 brown)	4	4	4	4	4
8	13224-371-003	Bearing d, connecting rod (1&3 green)	4	4	4	4	4
8	13225-371-003	Bearing e, connecting rod (1&3 yellow)	4	4	4	4	4



79 Std	Serialnr	Areacode
-----------	----------	----------

	To 2025227	
4		
	To 2025227	
-4		
	To 2025227	
-4		
	To 2025227	

2



