



Nr	Partnr	Description	75 Std	76 Std	76 Ltd	77 Std	78 Std	79 Std	Serialnr	Areacode
1	52400-371-003	Shock absorber assy., RR.	2	2	2	2				
1	52400-371-611	Shock absorber assy., RR.	2	2	2	2				
1	52400-371-980	Shock absorber assy., RR.	2	2	2	2				
1	52400-431-671	Shock absorber assy., RR.					2		To 4002775	
1	52400-431-672	Shock absorber assy., RR.					2	2		
2	52401-371-000	Spring, RR. Shock absorber	2	2	2	2				
2	52401-371-980	Spring, RR. Shock absorber			2					
2	52401-431-671	Spring A, RR. Shock absorber					2	2		
3	52402-431-671	Spring B, RR. Shock absorber					2	2		
4	52403-371-003	Joint comp., upper	2	2	2	2				
4	52403-371-980	Joint comp., upper			2					
4	52403-410-003	Joint comp., upper					2		To 4002775	
4	52403-410-013	Joint comp., upper					2	2		
4	52459-371-003	Seat, spring upper	2	2	2	2				
4	52459-371-980	Seat, spring upper			2					
5	52404-431-671	Joint, RR. Shock spring					2	2		
6	52410-371-003	Damper comp., RR.	2	2	2	2				
6	52410-371-980	Damper comp., RR.			2					
6	52410-431-671	Damper comp., RR.					2	2		
7	52422-371-003	Adjuster, spring	2	2	2	2				
7	52422-371-980	Adjuster, spring			2					
7	52422-410-003	Adjuster, spring					2	2		

Nr	Partnr	Description	75 Std	76 Std	76 Ltd	77 Std	78 Std	79 Std	Serialnr	Areacode
8	52457-431-670	Seat, spring middle					2		To 4002775	
8	52457-431-670	Seat, spring middle					4	4	From 4002776	
9	52458-410-003	Seat, spring under					2	2		
10	52484-292-000	Rubber, joint	2	2	2	2	2	2		
11	52517-385-000	Rubber, stopper	2	2	2	2				
11	52517-410-003	Rubber, stopper					2	2		
12	90301-376-003	Nut, hex., 11mm					2	2		
12	90301-385-003	Nut, hex., 11mm	2	2	2	2				
13	90309-315-000	Nut, RR. Shock absorber upper	2	2	2	2	2	2		
13	90309-371-980	Nut, RR. Cushon upper			2					
14	90521-292-000	Washer, 10.3mm	2	2	2	2	2	2		
14	90521-371-980	Washer, 10.3mm			2					
15	91511-371-980	Bolt, hex., 10x32			2					
15	93200-10032-0B	Bolt, hex., 10x32	2	2		2	2	2		
15	93201-10032-0B	Bolt, hex., 10x32	2	2		2	2	2		
	52458-371-003	Guide, spring	2	2	2	2				